



V2GO GO-100 Plus Firmware Updates

The firmware updates are used for updating your product's firmware settings and/or addressing certain technical issues. Please note the program is applicable for products on the NTSC video system rather than PAL. In case you need program for PAL, please send request to customerservice@v2gotech.com for more assistance.

Before installing the program, please read carefully the installation instructions as below:

Firmware Update Instructions

- 1. Download and extract the appropriate zipped file to your computer. Initially, be very careful to make sure the zipped file you download is for your product model number. Otherwise firmware damage may occur. Please contact technical support if you have any questions.**
2. Burn the file to CD disc or save to USB flash drive.
- 4. Please note the file cannot be opened by computer. It's readable only by V2GO machine.**
5. Turn on the machine and make sure it's hooked up with TV. Put in the disc or hook up USB flash drive through USB port.
6. Machine will scan CD disc or USB flash drive automatically and reads the file.
- 7. During updating, make sure you do not turn off the power, doing so may cause damage.**
8. After finishing the updating, the tray will open automatically.
9. Turn off the power and unplug flash drive. Turn on machine after 5 seconds.